


N300515
65101-11743

Installation Instructions

Honeycomb Shade Decoflex



Getting Started




Remove the shade & frame from the package. Save the packaging until the shade & frame are installed and working to your satisfaction.

Recommended Tools




- Power drill and drill bit
- Measuring tape
- Screwdriver
- Level
- Pencil



You will need to use the following fasteners for your particular mounting surfaces:



Surface	Fastener
Wood	1.5" Screw 
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide) 
Metal	Sheet Metal Screws (Not Provide) 

Check Hardware





Step 1. Assemble the Frame

Take frame insert off from the frame, and then assemble the frame together with Hoffman key at the back of the frame.



Step 2. Install the Frame


Place the shade in desired position, and fix the left-side frame and right-side frame with one 1.5" screw respectively. And then adjust the frame to make sure the frame is square and the diagonal line is in the same length. Secure the rest screws after adjusting the frame to square.



After all screws are secured, re-attach the frame insert to the frame.

Step 3. Install the Shade


Install the Cord Equalizer Housing Cover onto Cord Equalizer Housing Base which is pre-installed on the frame, by pushing down the Cover from top of the notch then slide to the side to match the Base. Make sure that cords are nice, tight and not tangled.



For child safety, please check and ensure that there are no loose cords after the shade is completely installed.

Step 4. Handle Installation

Slide the handle onto the plastic piece pre-attached to the rails.




Step 5. Adjust the Shade

After the shade is completely installed, use the handle to raise the shade up to the top and adjust the shade to level. Then you may operate the shade to any desired position.

Step 6. Remove the Shade

Operate the shade to the middle from top and bottom. Remove the Cord Equalizer Housing Cover from the Cord Equalizer Housing Base.



Cleaning Instructions

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).

